

8626 Series Mechanical Dual Time Setting Instructions



Watch Crown

Turn the crown clockwise at normal position for winding.

When setting the time, gently pull the crown to position A and follow the steps below.

- Turn the crown clockwise to set the destination time(away time)
- When the destination time is set, turn the crown counter-clockwise until you feel a click, destination time is now locked!
- Continue to turn the crown counter-clockwise to set the Home time. (Note: you will see the minute hand of the destination time still moving, but this will not affect or change the destination time you just set). While setting home time, also note the Sun/Moon indicator will be changing. Set it to the correct AM/PM setting.
- Once the correct home time is set, push back the crown back to the normal position.

Destination Time

*away time or time of another time zone

Home Time

*your home, everyday time

Sun & Moon

*used to indicate AM(sun) or PM(moon)

Very Important!

Please note, do not overwind your timepiece as it will damage the mainspring.

For proper time keeping, you will have to wind your watch daily, please turn the crown clockwise until you feel a slight resistance..

